

Damaged sheet flooring can be repaired quickly and easily by following the steps outlined below:

1. Cut around the damaged area in a neat circle or square.
2. Remove the damaged section of flooring.
3. Scrape any old adhesive of the subfloor.
4. Repair any damage to the subfloor.
5. Cut a piece of matching flooring to suit.
6. Glue the piece in place using a suitable adhesive.
7. Finish by welding the joints with a matching weld rod.

Please contact Gerflor on 1800 060 785 for any further information.

